

Operation Instructions:

- Clean the surface where you wish to install ArcMount.
- Peel off the protective film on the 3M adhesive pads at the bottom of the base.
- Place ArcMount's base on the surface and adjust the legs to conform with the surface you wish to install ArcMount.
- Press firmly for 15 seconds.
- Place your MagSafe-compatible smartphone on ArcMount as required.