

Operation Instructions:

- Insert the MagDrive-R into the AC vent slot using the AC vent mount or on the dashboard using the dashboard mount.
- Pull out the Retractable USB-C cable of MagDrive-R and plug it into your car charging adapter.
- Place your magnetic wireless charging smartphone on MagDrive-R.
- Foreign Object Detection (FOD) will trigger if MagDrive-R detects a foreign metal object on the charging plate. Remove the foreign metal object and place your smartphone back on the charging plate to resume charging.

Note: A Quick Charging 3.0 adapter or an adapter with an output of 30W and higher is recommended for the best charging performance.