

User Guide

Punch

High-Fidelity Mini Bluetooth Speaker with MagSafe Compatible Base

Introduction

Unleash the power of Punch, a 3W Bluetooth 5.3 wireless speaker that goes beyond sound with 40mm dynamic drivers for immersive music experiences. With TWS technology you can easily connect two Punch speakers and enjoy sound like no other. Punch features a MagSafe-compatible base for unparalleled convenience, effortlessly attaching to your iPhone and providing a distinctive and user-friendly listening experience. Control your audio effortlessly with a multifunctional button, and enjoy up to 12 hours of continuous playtime in a sleek and ultra-mini design. Attach and amplify your music with Punch – where style meets performance.

Packaging Contents

- Punch
- User Guide
- USB-C Charging Cable

Specifications

- Bluetooth Version: V5.3
- Bluetooth Profiles: A2DP//AVRCP/HFP/SPP
- Bluetooth Frequency: 2402MHz-2480MHz
- Bluetooth Chipset: JL AC6956C8
- Input Rating: DC 5V/350mA
- Driver Diameter: 40mm
- Speaker Output: 3W
- Frequency Range: 120Hz-20kHz
- Impedance: 3Ω
- Sensitivity: 83dB
- Signal to Noise Ratio: 75dB
- Battery Type: Li-Polymer
- Battery Capacity: 700mAh 3.7V 2.59Wh
- Operating Distance:
 - Device: 10m
 - TWS: 5m
- Music Format Supported: SBC/AAC
- Total Charging Time: 3 hours
- Total Playtime: 12 hours @ 50% Volume
- Charging Cable length: 57cm
- RF Output Power: <=20dBm

Features

- **40mm Dynamic Drivers:** Experience acoustic bliss with Punch a 3W wireless speaker with 40mm dynamic drivers that lets you feel every beat of your music when you hear it.
- **True Wireless Stereo Sound:** This brilliant, truly wireless, Bluetooth v5.3, speaker delivers sound like no other. Connect two Punch speakers and enjoy True Wireless Technology.
- **MagSafe Compatible Base:** Experience seamless audio enjoyment with Punch, featuring a MagSafe compatible base that effortlessly attaches to your iPhone, delivering a unique and convenient listening experience.
- **Multi-Functional Button:** Enjoy complete control over the listening experience using the built-in multifunctional button.
- **Long-Lasting Battery:** Play your favorite tracks for up to 12 hours with Punch and enjoy non-stop entertainment.
- **Ultra Mini Design:** The ultra-mini, lightweight design makes this powerful yet compact Bluetooth speaker highly portable.

Compatibility

Punch can be paired with any Bluetooth-enabled device.

Precautions

Please read all safety instructions and warnings thoroughly before using this product. Improper use of this product may result in damage to this or attached products.

1. Do not disassemble the product or attempt to fix it.
2. Kindly use the original charging cable provided to charge the product.
3. Do not attempt to replace any part of this product or battery inside.
4. Do not crush, puncture, dispose of in a fire, short the contacts or expose the product to water or other liquids.
5. Do not store or use the product in a high-temperature environment, including intense sunlight or heat.
6. Avoid drops, bumps, abrasions, and impacts.
7. If there is any reason to believe that there is damage to the product, discontinue use immediately.
8. If you find that the product is too hot, is emitting an odor, or is deformed, punctured or exhibits any suspicious or abnormal behavior, discontinue use immediately and contact our customer service.
9. Always charge this product before extended storage.

Appearance & Interface Description

1. Multifunction Button
2. Microphone
3. USB-C Charging Port
4. Charging Indicator
5. Status Indicator

Operation Instructions

1. Turning Punch On/Off

- Press and hold the Multifunction button for 2 seconds to turn on/off the speaker.

2. Pairing Punch

- The speaker enters Bluetooth mode automatically when turned on.
- Turn on the Bluetooth function of the device you wish to connect and search for "Promate Punch" from the list of found devices, select "Promate Punch".
- Punch will pair automatically with the last connected device.

3. Controlling Music Playback

- **Music Play/Pause:** Short press the Multifunction button to play/pause music tracks
- **Music Track Control & Volume Control:** Control the following functions via your Smartphone or Connected Device.

4. Hands-Free Function.

- Short press the multifunction button to answer incoming calls.
- Short press the multifunction button to end an ongoing call.

5. Charging Punch

- Connect one end of the provided charging cable to the Punch speaker and the other end to a USB charger, Power indicator light will light up orange during charging.
- The Power Indicator light will light up green when fully charged.

6. TWS Function

- Turn on both Punch speakers.
- Pair one of the speakers with your Smartphone or other Bluetooth Device, while keeping the other speaker not connected to any device.
- Double press the Multifunction button on both speakers, the status indicator of both speakers will flash blue and white alternately.

- Once pairing is completed, the status indicator light will turn solid blue on the left channel speaker and solid white on the right channel speaker.
- Both Punch speakers will reconnect automatically in TWS mode and pair with the last connected device.
- To disconnect or unpair both speakers out of TWS mode. Press the Multifunction Button 3 times on both speakers.
- After operation, both speakers will enter default pairing mode with status indicator lights flashing blue.

Troubleshooting

1. Punch does not pair with a Bluetooth device:
 - Check if the Bluetooth hardware on your device supports the A2DP profile, which is necessary for sound transmission over Bluetooth.